

---

### Cornering Kit Installation.

**Step 1:** Drill a 3/8th hole in the center of vertical side of the bale chamber as shown

**Step 2:** Put the spring on the chain. Starting in about 4 links from an end, hook the spring onto the chain, leave about 6-7 links of slack to allow the spring to stretch and hook the other end of the spring into the chain.

**Step 3:** Jackknife baler and accumulator to max or around 90°.

**Step 4:** On the long side of the turn, hook the end of the chain with the spring on it to the plate on the bale chamber, leaving three links hanging. Hook the other end of the chain onto the accumulator, making the chain snug.

**Repeat** for the opposite side. After setup, check the adjustment by turning with a bale in it and verifying that the spring has tension on the bale

When unhooking the accumulator from the baler, release the baler end of the chain in order to retain the setting.

This picture is taken while turning.



When you are going straight, the chain will be sagging like this.

